

Since 1968

COMMAX
SmartHome & Security

User Manual

Door Camera CIP-D20YS



COMMAX Co.,Ltd.



- Thank you for purchasing COMMAX products.
- Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow instructions to use a product exactly.
- The company is not responsible for any safety accidents caused by abnormal operation of the product.



Contents

1. Introduction	2
2. Part Names	3
3. Wiring and Installation.....	4
4. Package Contents	5
5. Specification	6



1. Introduction

Your unit is designed so it can be flush mounted on the wall or used. When flush mounted on the wall, the stand permits you to view the unit for an angular view. The model number is located on the bottom and record the serial number in the space provided below (available). Refer to these numbers whenever you call upon your COMMAX dealer regarding this product.

Model No. _____ Serial No. _____

To prevent fire or shock hazard, do not expose the unit to rain or moisture.



This symbol is intended to alert the user to the presence of uninsulated **"dangerous Voltage"** within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



caution


Risk of electric shock
do not open



CAUTION: To reduce the risk of electric shock, do not remove cover (or back) no user-serviceable part inside refer servicing to qualified service personnel



2. Part Names






No.	Information	No.	Information
1	Camera	6	Button lighting
2	MIC	7	DC 12V
3	LED & CDS	8	Reset Button
4	Speaker	9	LAN(POE)
5	Call Button	10	DOOR RELEASE

- Press the Reset button for 5 seconds, you can initialize status of camera.




3. Wiring and Installation




- 1) Match the fix the whole in the wall and the fixing bracket.
- 2) Connect UTP cable on the back side of a door camera.
- 3) Adjust camera location on the wall by checking the image on monitor screen and fix its location.
- 4) Connect the Door Release Connection Line as shown.
- 5) Tighten a screw at the bottom side of the camera.



4. Package Contents



Entrance Camera
(CIP-D20YS)



Mounting Bracket



Manual



T4X18 (2EA)
Bracket Fixing Screw



M3X8 (1EA)
Camera Fixing Screw



5. Specification

	CIP-D20YS
Power Source	PoE DC 36~54V / DC 12V(option)
Power Consumption	Standby : 2.5W , MAX : 5W
Wiring & Distance	UTP (CAT.5e) Standard 70m (Standard distance from PoE S/W)
Pixel	2M CMOS
Video	H.264
Mount Type	Surface
Temperature	- 10°C ~ +40°C
Angle	125°
Dimension(mm)	106.8(W)×165.0(H)×50.4(D)

* Default ID : admin, Default password : 123456789